

WOODWARM STOVES

Installation and Operating Instructions for The Wildwood Free Standing Stove Range.

*Please read this booklet thoroughly before attempting to install or use
this appliance.*

Includes Registration and Guarantee Document.



Serial Number

*Also detailed on data plate located on the
back of the stove*

Please quote when making an enquiry

M_____:_____

Boiler : _____

Canopy: _____

A new era in clean, effective Wood Burning stoves.

WOODWARM STOVES

Woodwarm Stoves (Est. 1974)

By

Metal Developments Ltd

The Workshop, Wheatcroft Farm, Cullompton, Devon EX15 1RA

Tel : 01884 35806 Fax : 01884 35505

www.woodwarmstoves.co.uk



List of Contents

General Specifications	Page 3
Cautionary Notes on Use	Page 4
Regulations and Installation Instructions	Page 4
Hearth	Page 4
Stove Site and Minimum Clearances	Page 5
Chimney and Flue	Page 5
Air Ventilation and Free Air	Page 5
Flue Appliance Outlet Positions	Page 6
Flue Outlet Configuration	Page 7
Installing the Stove	Page 8
Baffle	Page 9
Internal Fireboards	Page 9
Fire Doors	Page 10
Glass Panels—Cleaning and replacement	Page 10
Commissioning	Page 11
Fuels for Burning on Wildwood Stoves	Page 11
Daily Routine, Maintenance and Servicing	Page 12
Operating Instructions for the Woodwarm Wildwood Stoves	
How Clean Burn Works	Page 12
Initial Lighting	Page 12
Lighting	Page 12
To Achieve Cleanburn	Page 13
Overnight Burning	Page 17
Plumbing Notes	Page 14
Ordering and Installation of Retrofit Boilers	
Slab Boilers	Page 15
Split Saddle Boilers	Page 15
Removing Boilers	Page 16
Pipe Thermostats	Page 16
Typical Central Heating Layouts in Conjunction with Split Saddle Boilers	
Typical 2 Pipe Central Heating Circuit	Page 17
Typical 4 Pipe Central Heating Circuit	Page 18
Roof Boilers	Page 19
Aquastat Calibration	Page 20
Fault Finding	Page 21
Fume Emission	Page 21
Wildwood Double Stoves Additional Installation and Operating Instructions	Page 22
The Woodwarm Guarantee	Page 23
Details of Product Registration	Page 24
Spare Parts	Page 24

General Specifications - Wildwood Freestanding Stoves



Class 1: BS EN 13240:2001 + Amd 2:2004.

For Intermittent use only.

Unsuitable for use in a shared flue system.

Use only recommended fuels.

Table 1

Air Inlet grills must be so positioned that they are not liable to blockage.

Model	5.0Kw	6.0Kw	7.0Kw	9.0Kw	10Kw Plus	12.0Kw	12.0Kw Plus	14Kw	16.0Kw	20.0Kw
Nominal Heat Output Kw	5	6	7	9	9.6	11.6	11.5	14	16	20
Space Heating Kw	5	6	7	9	9.6	11.6	11.5	14	16	20
Efficiency %	79.1	79.1	78.5	78.5	71.7	73.6	74.0	73.6	73.6	73.8
Flue Gas mass flow g/s	4.0	4.3	6.1	6.1	8.0	7.4	10.4	10.9	12.8	12.8
Mean Flue gas Temp °C	273	313	313	364	364	376	376	411	411	403
Weight										
Minimum Clearance From Inflammables (without Woodwarm heat deflector)										
Rear	700mm	700mm	900mm	900mm	950mm	950mm	950mm	1000mm	1000mm	1000mm
Side	450mm	450mm	450mm	450mm	550mm	550mm	550mm	550mm	550mm	500mm
Minimum Clearance From Inflammables (with Woodwarm heat deflector)										
Rear	220mm	220mm	220mm	220mm	220mm	220mm	220mm	220mm	220mm	220mm
Side	110mm	110mm	110mm	110mm	110mm	110mm	110mm	110mm	110mm	110mm
Recommended Refuelling Intervals										
Hours	1.5	1.5	1.5	1.5	1.5	1.5	1.5	1.5	1.5	1.5
Maximum Log Length	368mm	368mm	368mm	430mm	483mm	483mm	483mm	558mm	588mm	635mm
Overall Height										
Flat Top	682mm	682mm	722mm	722mm	766mm	725mm	766mm	758mm	758mm	750mm
Low Curved Canopy	899mm	899mm	979mm	957mm	1016mm	982mm	1016mm	1080mm	1080mm	1072mm
High Curved Canopy	n/a	1014mm	n/a	1088mm	n/a	1102mm	1131mm	n/a	n/a	n/a
Overall Width										
Flat Top	555mm	555mm	652mm	652mm	680mm	687mm	680mm	750mm	750mm	800mm
Low Curved Canopy	604mm	604mm	710mm	710mm	750mm	750mm	750mm	813mm	813mm	865mm
High Curved Canopy	n/a	593mm	n/a	710mm	n/a	750mm	750mm	n/a	n/a	n/a
Overall Depth										
Flat Top	402mm	465mm	400mm	463mm	438mm	537mm	537mm	460mm	535mm	585mm
Low Curved Canopy	402mm	465mm	400mm	463mm	439mm	539mm	539mm	465mm	540mm	585mm
High Curved Canopy	n/a	465mm	n/a	463mm	n/a	537mm	537mm	n/a	n/a	n/a
Flue Outlet Size	152mm	152mm	152mm	152mm	178mm	152mm	178mm	178mm	178mm	178mm
Height to Centre of The Rear Flue	532mm	532mm	521mm	521mm	548mm	523mm	548mm	540mm	540mm	523mm
Top Flue - Centre Line To Rear										
Flat Top	168mm	197mm	172mm	198mm	198mm	198mm	216mm	216mm	216mm	216mm
Low Curved Canopy	n/a	162mm	n/a	163mm	n/a	163mm	163mm	155mm	185mm	205mm
High Curved Canopy	n/a	162mm	n/a	163mm	n/a	163mm	163mm	n/a	n/a	n/a
Stove Fire Boards										
Side Board(mm) (2 Required)	340x195	340x265	380x240	380x305	432x290	380x380	432x386	390x306	390x380	425x410
Rear Board (mm)	393x270	393x270	478x250	478x250	515x280	515x245	515x280	580x255	580x255	635x240

Cautionary Notes on Use

De-Ashing

we would strongly recommend that de-ashing is only undertaken when the fuel load is exhausted, the stove is out or in a very low state. Furthermore.

Maximum Temperature - Over-firing the Stove - Use Beyond the Rated Output

The stove body is designed to run up to a maximum temperature **not exceeding 700F or 400C (the stove firedoor must be kept shut at all times except when re-fuelling or de-ashing the stove)**. We recommend the use of a stove thermometer available from your dealer or us.

There are 4 possible causes for stoves over-heating :-

- 1 Primary air vents left open.
- 2 The ashpit door or fire door rope seals worn or damaged or missing. They should be replaced if necessary or they can be pulled out, adjusted and easily re-placed in their channels. No fixative is needed.
- 3 Check that the rope seal between the stove body and its canopy is in position.
- 4 Excessive chimney draw (the minimum flue draft for nominal heat output is:- not exceeding 0.15 mbar (0.06" water gauge)). If it is high use remedial action; either the fitting of a flue stabiliser to the flue as close to the appliance as is aesthetically possible, the fitting of a flue damper in the chimney, or a chimney cowl. (Ask your dealer or contact us for details).

Chipboard and other composite wood-type materials contain corrosive additives, especially when **mixed with wet wood**, that may etch and permanently damage the surface of the glass.

A reminder to the installer.

All the split saddle boilers are two physically separate boilers that must be linked at the rear of the stove and tee'd off to the flow and return pipes.

The Boiler circuit should have an Inhibitor added to it.

REGULATIONS AND INSTALLATION INSTRUCTIONS FOR THE WOODWARM WILDWOOD STOVES

All local regulations, including those referring to national and European Standards (BS 6461, Installation of chimneys and flues for domestic appliances burning solid fuel (including wood and peat) & BS 8303, Code of practice for installation of domestic heating and cooking appliances burning solid mineral fuel) need to be complied with when installing this appliance.

Health and Safety at Work

It is the responsibility of the installer to comply with current Health and Safety Regulations, and particular attention should be given to the following:-

Asbestos

This stove contains no asbestos. If there is a possibility of disturbing any asbestos in the course of installation then please seek specialist guidance and use appropriate protective equipment.

Handling

This stove is heavy and adequate facilities must be available for all handling operations and its final manoeuvre into position. In order to lighten the stove, the main door may be removed. The baffle and grate bars can also be removed.

Glass

Care should be taken when handling the door that the glass is not knocked. The door is double glazed.

Fire Cement

Some types of Fire Cement are caustic and should not be allowed to come into contact with the skin. In cases of contact, wash off with plenty of water.

Electrical

If any electrical components are used in the installation they should be installed in accordance with the manufacturers installation instructions and all wiring must comply with the current I.E.E regulations and the by-laws of the local water authority.

Air Supply

Building Regulations dictate that an air vent of some type (usually an air brick) must be fitted into an exterior wall to allow sufficient flow of air into the fire. **Air Inlet grills must be so positioned that they are not liable to blockage.**

This stove should not be fitted in a room where an extractor fan is in use, as this could result in flue reversal and the emission of flue gases into the room.

HEARTH

The stove must stand on a fireproof hearth which must be at least **127mm thick and constructed of a non-combustible material**. The positioning of the stove and the size of the hearth is governed by Building Regulations for Class 1 Appliances. These regulations state that the hearth must extend at least **225mm** in front and **152mm** to the side of the stove. This can be covered with decorative tiles so long as these are also non-combustible.

SUPER IMPOSED HEARTH

In certain circumstances Building Regulations allow for a super imposed hearth. **This must be a minimum 12mm non-combustible material** e.g. slate, glass, steel. When the stove is raised **100mm** or more (the standard Wildwood stove has legs incorporated into its design will raise the stove over 100mm) the hearth temperature does not exceed **100°C**, which complies with Building Regulations.

STOVE SITE AND MINIMUM CLEARANCES

There must be **no combustible** material (i.e. plaster board, wooden wall panels, skirting boards, beams etc) **within a specified distance to the rear and sides of the stove, these can be found on table 1 page 3.**

The clearance between the stove and any non-combustible surface is recommended as **not less than 152mm.**

To reduce the above clearances we recommend the use of the **Woodwarm Heat Shield**, which can be wall mounted to the rear or the side of the stove.

CHIMNEY AND FLUE

The chimney should be thoroughly swept and examined for soundness. If the chimney is not lined, then we recommend strongly that before use it is fully lined with a **Class 1 Liner and insulated. It is not advisable to only partially line a chimney as this will only create further problems where the lining finishes.** If there are even the smallest air breaks in the mortar, the chimney is not suitable for a wood stove. When hot flue gases rise up the chimney, it will pull cold air through any small break. This cools the flue gases at that level causing wood tar to precipitate at that point on the chimney wall. Soon this will accumulate across the chimney and therefore constrict it and stop the fire burning properly. Eventually this will not only lead to a chimney fire, but will further rot the chimney structure. If the chimney is not lined and was previously used for an open fire then there is a possibility that the higher temperatures produced by this closed appliance will loosen deposits. It will be necessary to have the flue swept and inspected by a registered sweep one month after the initial installation.

In the absence of a chimney one of the following must be used either internally or externally:- a prefabricated block chimney, a conventionally constructed chimney with a Class 1 liner, or a twin walled insulated flue to BS 4543. **The internal diameter must not be less than that of your particular appliance.** Flues must be fitted in accordance with the manufacturers' instructions and according to local Building Regulations. If there is any doubt over the flue connection or the installation, consult your nearest professional installer, or the Building Inspector at your local council.

Whichever chimney option you choose to use **DO NOT FORGET TO POSITION A CLEANING ACCESS**

(if applicable) in your flue and chimney that is easily accessible for sweeping. **Note:** Clay liners can create a cool upper internal temperature which can lead to condensation problems, especially if the liners are not back insulated. If a clay liner is already in place we recommend lining with class 1 liner.

For efficient stove working it is important to make sure that there is an adequate draw on the chimney. The chimney height should not be less than 4 metres measured vertically from the outlet of the stove to the top of the chimney. With a minimum flue draft reading of 0.05mbar (0.02"wg) when warm, increasing to 0.15mbar (0.06"wg) when hot. These readings should be taken using secondary air and all fire doors closed. The minimum flue size for these stoves varies according to the model, refer to the specification sheet (table 1 page 3) for the minimum flue diameter. If possible line the chimney with a flue liner that is at least 25mm (1") larger than that of your particular stove. At no point in the flue should it be below the minimum flue diameter.

When the stove is to be connected to an existing fireplace, this will need sealing to the flue by a register plate, which can be mounted horizontally or vertically.

This appliance is unsuitable for use in a shared flue system. If elsewhere in the house another fireplace feeds into the same chimney this **must** be sealed, otherwise flue gases or air may either be drawn into or escape from, the other chimney or fireplace. This would contravene Building Regulations as it is potentially **very dangerous.**

CHIMNEYS, FLUES, COMBUSTION, AIR SUPPLY AND POSITIONING OF THE STOVE

In addition to these installation instructions, Building Regulations and Local Authority By-Laws regarding flues and positioning of the appliance. (Building Regulations **Document J** must be observed).

AIR VENTILATION AND FREE AIR:

The stove requires 550 mm² of FREE AIR space per KW input in excess of 5kw. Therefore, a 9kw input appliance requires 2200mm of free air.


$$9KW - 5KW = 4KW$$

$$4KW \times 550mm^2 = 2200mm^2$$


There must not be a extractor fan fitted in the same room as the stove as this can cause the stove to emit fumes into the room.

Flue Appliance Outlet Positions

Diagram 1



Point where flue passes through weather surface (Notes 1,2)		Clearances to flue outlet
A	at or within 600mm of the ridge.	at least 600mm above the ridge.
B	elsewhere on a roof (weather pitched or flat)	at least 2300mm horizontally from the nearest point on the weather surface and: a) at least 1000mm above the highest point of intersection of the chimney and the weather surface; or b) At least as high as the ridge.
C	below (on a pitched roof) or within 2300mm horizontally to an openable roof-light, dormer window or other opening. (Note 3)	At least 1000mm above the top of the opening.
D	within 2300mm of an adjoining or adjacent building, whether or not beyond the boundary. (Note 3)	at least 600mm above the adjacent building.
Notes 1) The weather surface is the building external surface, such as its roof, tiles or external walls. 2) A flat roof has a pitch less than 10°. 3) The clearances given for A and B, as appropriate, will also apply.		



The datum for vertical measurements is the point of discharge of the flue, or 150mm above the insulation, whichever is the lower

Flue Outlet Configuration






Diagram 2



INSTALLING THE STOVE

Place **stove** on chosen level hearth and remove any packaging materials. The shrink polythene can be used as a cover for the stove whilst installation is in progress as fire cement will mark the stove paint surface if left. If needed the canopy of the stove may be removed and placed to one side by lifting upwards. Ensure that the rope in the channel of the underside of the canopy is not discarded, as this is the seal between the canopy and the body of the stove.

There is normally a piece of **cardboard**, for protection, behind the door glass. All other pieces of board in the stove are the **fire boards**. Turn the knob and open the fire door then carefully remove it by lifting up and off its hinge pins (retaining these) and place it safely out of the way. From the front of the stove you can now remove **the operating tool, flue spigot, flue blanking plate, baffle, fire boards and fire board retainer brackets** (two on 9kw and Double stoves only).

The stove can be **levelled** by using the levelling bolts at the base of the legs, or you can fix the stove to the hearth through the bolt holes. Additional brackets are supplied with the 5kw, 7kw and 10kw slim line stoves. These brackets should be fitted and used to secure the stove to improve stability.




Diagram 3

Additional brackets supplied on slim line stoves only. These should be fitted and used to provide additional fixing points for securing the stove (to improve stability).

The **airwash cover** (9kw & 12kw only) is located along the top rear of the air channel above the main door, its two pins fitting in the two holes, one at each end of the channel. If it has been dislodged in transit, ensure it is repositioned.




Diagram 4

Replace the **canopy** if removed and check the base to ensure that the rope which makes the seal between the canopy and the body of the stove is in place (if needed it can be held in place with a smear of fire cement).

The flue spigot supplied with the Woodwarm is either 152mm or 178mm depending on your model. It is designed to be used for top or rear mounting and is interchangeable with the blanking plate if a different flue position is required at a later date. A smear of fire cement should be applied to the flange of both the blanking plate and the flue spigot to ensure an air tight seal. Locate the **blanking plate** and the **flue spigot** in their chosen apertures and then rotate each clockwise through about 15 degrees to lock them. **Ensure seal is secure and airtight.**

Fire cement and/or a length of fireproof rope should be used to seal the join of the **flue pipe** and the flue spigot, the joint between two **flue pipes** and where the flue pipe joins your chosen **register plate**. Stainless Steel self-tapping screws or nuts and set screws should be used to reinforce the above joints where applicable.

Carefully remove any excess fire cement immediately to ensure no marking of the stove finish.

Replace the fire board retainer brackets (9kw and Double stoves only) fire boards, baffle, grate bars and log guard followed by the ashpan and finally the main fire door. (**For fitting instructions of fire boards and baffle see diagram 5**).

BAFFLE

The smoke baffle sits on the rear fire board and locates on the baffle support pins in the top of the stove (front pins on two pin models). Fit baffle as shown in Diagram 3. Ensure baffle seats squarely on rear board.


INTERNAL FIRE BOARDS

These stoves are for both wood and solid fuel and the interior of the fire chamber of all of them is lined with 30mm Mica based fire resistant board. There are three pieces, one at the rear under the baffle and flue outlet and one on either side or, if boilered only on the non-boilered sides of the stove. These fire boards are ready cut, to size and shape and may be packed loose to prevent damage. They are very fragile so **handle with care**, especially when loading with fuel. They have a relatively short life, especially when burning coal, so do inspect them regularly and replace if they begin to deteriorate by showing signs of breaking up or wearing thin. The fire board is important for efficient combustion and is not covered by any warranty as it is considered a consumable product.

A table of replacement sizes is provided under **Stove Fire boards** on **table 1 page 3**.

Fitting of Fire Board and Baffle

Diagram 5



FIRE DOORS FOR ALL MODELS

Check when refitting the fire door that the rope seal on the inner face of the door is making an even contact with the stove body when the door is closed. Your New Wildwood Stove has a new style door catch to make it easier and safer to use your stove. Use the tool provided to locate onto the upright part of the door catch and turn to the left to open and to the 'lock' position to close. If necessary this door catch can be adjusted, by loosening the lock nut (shown in blue diagram 6) with an 8mm spanner. Rotate the dome headed set screw (shown in green) anti-clockwise to tighten and clockwise to loosen seal, then re-tighten the lock nut.




Diagram 6

Important

It is very unusual to have to re-align the fire door. This job is very fiddly and only to be attempted if necessary. The doors are jigged at the factory for alignment to the stove body, but should you need to adjust them use a 10mm spanner and adjust the bolts attaching the hinges to the stove body. The hinge block is fastened to the body of the stove through an enlarged hole giving adjustment horizontally, and on shim plates giving adjustment of the throw of the door to the stove body.

On side mounted hinge models you will need a 13mm spanner, and 5mm allen key to adjust the allen grub screws in the hinge block, this gives movement in all directions and is fiddly to adjust.

Method clue :- Have the fire door open at 90° to the stove and then only partially loosen the fixing bolt so that the mechanism does not become loose.

GLASS PANELS AND CLEANING

There are two panels of glass in each door. They are made of a heat resistant ceramic product which will not break with the heat of the fire. However, it is important to maintain the movement of the glass within the door as, if the glass is restricted, it is likely to crack with the expansion or contraction of the cast door. To achieve this it has heat resistant fibre glass ladder rope around the edges and this should be replaced if it is showing signs of deterioration.

The glass can be cleaned when hot without damage to the panel although care must be taken not to burn your fingers etc., also care must be taken with aerosol cleaners and cleaning cloths. We recommend the proprietary stove glass cleaners. When solid fuel is being burnt any sooty deposits on the glass can be cleaned simply by wiping with a dry cloth.


If the stove glass becomes dirty this is either due to the closing of the airwash before the fuel is up to temperature and/or wood fuel is too wet. If a routine is established of hard burning on secondary air only for 20 minutes at each end of the day this will assist in keeping your glass clean.

REPLACEMENT OF GLASS PANELS

Carefully lift the fire door from its hinge pins and lay it down - preferably on a soft substance - being aware of the door fastening catch. The outer glass panel (furthest from the fire) is mounted on fibre glass ladder rope which should surround all the edges (diagram 7). Caution is required when replacing this glass panel as the ladder rope has a tendency to slip out of position as the glass is fitted. The second or inner panel then fits directly on top of the outer followed by the top and bottom steel glass retainer and the whole held together by the 6 x (M4 x 10mm) machine screws. It is recommended to apply some heat resistant copper grease or graphite grease to the screws and **DO NOT OVER TIGHTEN THEM** as the glass panels will crack.

The stove requires both of these glass panels in place to achieve a clean burn state as they act in a similar way to double glazing in a domestic window.

Diagram 7



COMMISSIONING

On completion of the installation and after allowing a suitable period of time for any fire cement or mortar joints to dry out, the stove should be cleaned using a soft dry cloth. Check joints and seals, especially boiler connections. Ensure that any boiler connections are the right way round. (Flows are the top connection and returns the lower). The stove can then be lit and checked to ensure that smoke is taken from the appliance up the chimney and emitted safely.

The customer should be advised on the use of the appliance.

On completion of the installation and commissioning please leave these operating instructions with the customer.

HETAS LTD APPROVAL

These appliances have been approved by HETAS Ltd as an intermittent operating appliance for burning Wood.

ALWAYS BURN DRY WOOD. Wood burns **best on a bed of ash** (25mm recommended) so do be careful to retain some when de-ashing. Dry wood means that it has most **definitely not more than 20% moisture** content. Wood to be used as a fuel should be logged, chopped and **stored in a sheltered but airy site** for an absolute minimum of 12 months and **preferably 24 months**. Wood naturally dries at the rate of 1" per year so a 12" round will take 6 years to dry to the centre. **Do not be tempted to stack wet wood on or around the stove** believing this will dry the sap out of the wood. A 12" log takes approx 8 weeks in a kiln to dry to 18% moisture - so the odd hour or two on or by the stove only increases the likelihood of burning your house down! **Freshly cut green wood** - i.e. wood that still has sap in it - **is dangerous to burn**. It will cause a chimney to choke with wood tar in a few weeks with a grave risk of a chimney fire resulting. In any case, **burning sap wet wood is pointless**. It produces far less heat, maybe as little as 10% of that of dry wood.

Treat any bought in wood as wet unless its history is known.

Do not burn wet wood with solid fuel as a very aggressive acid is created which is lethal for the stove, chimneys and flues.

Do not burn treated wood.

Tar is caused by burning wet wood. It is brown/black in colour and may be liquid. It has an offensive smell. On the sides of the stove, flue and chimney it resembles a black sticky 'chewing gum' and can eventually block the flue ways. When it ignites, it can cause a chimney fire and be highly dangerous.

Please note that HETAS Ltd Appliance Approval only covers the use of the above fuels on these appliances. HETAS Ltd Approval does not cover the use of other fuels either alone or mixed with the recommended fuels listed above, nor does it cover instructions for the use of other fuels.

DAILY ROUTINE , MAINTENANCE AND SERVICING

When properly used a Woodwarm Wildwood stove is absolutely safe.

There is an **operating tool** provided to **operate all the various controls**. **Do not leave the operating tool attached to the stove when the stove is in use as it will get very hot.** Obviously when the stove is in use the body will be too hot to touch by hand. Children and elderly people should be prevented from touching it by accident by using a suitable fire guard. This should be manufactured to BS 6539.

Combustible materials should never be left on the stove when it is alight. Linen, wool, wood and many other materials can spontaneously ignite if they become too hot. They do not have to come in direct contact with flames. Never spray aerosols near the stove when it is alight as an explosion could occur if flammable vapours or gases come into contact with naked flames.

A routine should be established of :-

Daily - Check on the amount of ash in the stove and check that it is not blocking the primary air inlet. **run the stove hot for a time** using the procedure as explained on pages 10 and 11, along with a surface mounted thermometer to ensure optimum temperature is reached. This will assist in cleaning any marginal deposits of tar from the door glass, stove, flue and chimney internally.

Weekly - check seals, be they rope or fire cement, for air tightness. **LUBRICATE** the **fire door catch** if needed with a high temperature or graphite based lubricant.

Twice yearly - check the condition of the fire boards and seals and replace if deteriorated. Remove and clean over the baffle and clear flue ways. More often if burning solid fuel. A visit from the chimney sweep will remove the small amount of ash dust which forms in the chimney if the above instructions are adhered to.

The names and addresses of your local Approved Chimney Sweeps can be obtained from either of the following:- Guild of Master Sweeps or The National Association of Chimney Sweeps (see page 23 for contact details).

If the stove is to be left unlit for any period of time ensure the **air vents are left open** and the **controls and door catches are well lubricated** with a high temperature/graphite based lubricant or other rust preventative. Maintain the paint surface solely with a soft dry cloth and nothing more. The paint used is a durable heat proof paint. It is, as a consequence, porous and is not waterproof. Before re-lighting the stove after a long period out of use, check that **all flue ways are clear** of obstructions.

OPERATING INSTRUCTIONS FOR THE WOODWARM WILDWOOD STOVES

Before lighting check with the installer that the work and checks described in the previous pages of this booklet have been carried out correctly and that the chimney is sound, has been swept and is free from any obstructions.

HOW CLEAN BURN WORKS

The Wildwood range of stoves utilise long preheated air inlet ducts venting the air to the stove at the front top of the door aperture. This method of air inlet builds an '**Air Curtain**' over the glass and prevents all but a little of the normal tar deposits from condensing on the glass of the stove, and causes all, but a small proportion, to be burnt in secondary combustion, hence the '**CLEAN BURN**' application.

INITIAL LIGHTING


Note The paint used for finishing the stove will emit fumes as it "cures" when first fired, and maybe on the second firing, as the body of the stove reaches operating temperature. Therefore ensure the room is well ventilated. As part of the process the paint **will soften whilst "curing" so avoid touching as this will severely mark the finish.**

LIGHTING

Open the air control lever on the left hand side of the stove by pushing it down. Open the primary air inlet by sliding the knob to the left (**the primary air inlet is closed when the knob is centre to the stove**).

Make sure that the exterior of the stove is thoroughly cleaned using a dry cloth. The stove can be lit using paper, dry kindling, and/or fire lighters. Place the paper and kindling or fire-lighters in the stove and cover with wood. Light the fire and close the stove door; wait until the fuel is well alight then load fuel and adjust the air controls to suit as in the following section.

Diagram 8



TO ACHIEVE CLEAN BURN

This section applies for the burning of dry wood.

Take some time to familiarise yourself with the air controls of the stove (diagram 8) to achieve the clean burn state that these stoves are renowned for.

The **air wash** is controlled by the lever on the top left hand side of the stove.

When the lever is in the **UP POSITION** the air wash is **closed**.

When the lever is in the **DOWN POSITION** the airwash is fully **open**.

A) When lighting or refuelling the stove allow it to reach operating temperature every time, before attempting to close the air wash control lever. The glass will get dirty if the stove body has not reached the optimum temperature first and clean burn will not be achieved. We recommend that you use a magnetic surface-mounted **thermometer** (which can be purchased from your supplier or from ourselves) to achieve this. Place it on the body of the stove at the front right hand side just above the door hinges.

Regard the Primary air slider control like the choke on a car i.e. close them as soon as the stove is warm.

B) Leave the air wash air control open for about 20 minutes until the surface temperature of the stove body has reached a temperature of 250-280°C (450-500°F), as shown by the thermometer. Slowly close the air wash lever. Although use of the primary air slider will increase the draw of the fire, prolonged or excessive use of this under draught will cause dirtying of the glass, and can lead towards excessive over firing of the stove, therefore reduce under draught as soon as is practical.

C) **When refuelling the stove**, first open the top air control to increase the draw of the fire and allow the chimney to warm up, this will draw any smoke/fumes up the chimney when you open the main door. To maintain the hot air flow from the front of the stove to the rear, drag any unburnt fuel to the front and add new fuel to the rear. Try and keep the fuel at least 25mm from the door glass when the door is closed and repeat the procedure in B. For recommended refuelling intervals see table 1.

Time spent now will reward you and remarkable results should be achieved. This will be even more apparent to you if you have previously owned a conventionally draughted stove.

It will take a few loadings and firings before you become familiar with the air vents and amount of fuel necessary to achieve the burning rate you require. Try to load the stove with fuel enough i.e. not too small a load and not too large a load.

To be avoided at any time is loading the stove up and immediately closing all the air controls.

ADJUSTMENT OF THE PRIMARY AIR SLIDER

Occasionally the primary air slider may require adjustment. Using a 10mm spanner you can adjust the air slider nuts which are located underneath the base plate of the stove (diagram 9). **Caution must be taken, if the air slide is not correctly adjusted (to loose) the stove will continue to draw in air when the air control has been shut down.**




Diagram 9

Air Slider Adjustment Nuts

Air Bleed Control

A small air bleed hole adjustment is provided, it is either located on the airwash lever, or behind it. Its function is to allow you to "Set" the stove to the chimney draught. Open it fully and over the first couple of extended burning periods, monitor the result of your stove's slumber. If it fails to stay alight long enough, by burning through all the fuel too quickly, reduce the setting until you are happy. When you are, tighten up the self tapping screw, so that in future when you fully shut the airwash lever this hole will allow the stove to remain just open. Chimneys with a high draw may require this small air bleed hole to be closed.

Chimney Fires

If the chimney is thoroughly and regularly swept, chimney fires should not occur. However, if a chimney fire does occur turn the air control setting to the minimum, and tightly close the doors of the stove. This should cause the chimney fire to go out in which case the control should be kept at the minimum setting until the fire in the stove has gone out. The chimney and flue ways should then be cleaned. If the chimney fire does not go out when the above action is taken then the fire brigade should be called immediately.

After a chimney fire the chimney should be carefully examined for any damage. Expert advice should be sought if necessary.

Boilered Stoves Note:-

Cleanburn will be a little more difficult to achieve with boilered stoves. However perseverance to achieve as high combustion temperatures as possible will assist in keeping the glass clean.

EXTENDED BURNING PERIODS

When burning **wood**, thus if longer burning times are required use **dry** large logs of a hard wood rather than small ones, remembering to keep a bed of ash.

Some woods need more air than others to tick over, some experimentation will be necessary to find the right setting.

Remember to allow the stove to reach operating temperature before closing air controls.

Plumbing notes

Please read these notes prior to installing your Woodwarm boilered stove

- * A boilered stove will have a lower combustion temperature than a dry stove and will not reach the clean burn state as readily.
- * Always site the circulating pump on the return.
- * Do not fully pump a solid fuel stove as it is refuelled on a two hour refuelling cycle and may not be able to get it's heat load up to temperature when fully pumped
- * When a pump is used on the heating circuit ensure that it's action is controlled by pipe thermostats to stop it circulating water which is under 50°C
- * Ensure one third of the system can rise to a gravity section of the circuit.
- * Do not pressurize the system, always use an open vented circuit.
- * If combining two or more heat sources think of using a "Link Up" Neutralizer as part of the circuit, it will assist in even distribution from both heat sources.
- * Where there are two pumps in the system, possibly as above, there will need to be a three channel programmer incorporated such as the Honeywell ST699.
- * Do not directly plumb under floor heating into the circuit. For under floor heating there will need to be a heat store (Thermal Accumulator, thermal store)

A Heat Store is a very efficient way of using heat. A stove can be fired flat out to heat it, which is the most efficient way to use the boilered stove. The stove can then be allowed to go out, with the electric controls distributing mains pressure hot water and circulation water as and when required.

In choosing a heat store look for at least 100mm of insulation.

It can be plumbed directly to the stove but it must have the relevant safety measures and it must be a minimum 1800mm above the stove.

For size and heat calculations use 10 litres per square metre

One shower = 20 minutes = 10kw

40W/sq mtr new house

60W/sq mtr old house

80W/sq mtr draughty old mansion

Try www.heatweb.com for more details on Heat Stores

ORDERING AND INSTALLATION OF RETROFIT BOILERS

All the models have a variety of boilers that can be retro-fitted and have pre-drilled holes in the body and these are covered with blanking plates which can be knocked out using a hammer (**do ensure** you have the right holes by offering the boiler up to the holes **prior** to removing them) and when ordering boilers for retro-fit please state your stove model as **some need a change of baffle**. i.e. for the 53000 Btu split saddle boilers in the 20kw.

Boilers replace the fire boards and depending on the size of boiler to be fitted, remove the relevant board(s) or part thereof before fitting the boiler(s). With slab boilers the rear fire board may be larger than the boiler; cut the appropriate amounts from the fire board and fit them back either side of the boiler.

All the **boilers in the free standing models** have **1" Male BSP stubs**.

SLAB BOILERS


The slab boilers available for your stove are detailed in the current brochure under general specifications. They are available in stainless steel for 'Direct' Cylinders or steel for 'Indirect' Cylinders and have two **1" Male BSP stubs**. To fit the boiler remove the fire board and remove the relevant blanking plates. The two stubs are passed through the stove body holes and the nuts and washers are sealed (with fire cement or high temperature mastic, where the stubs come through the body) and tightened on the rear of the stove body. The higher boiler stub is for the gravity flow which should rise immediately from the boiler in 28mm pipe and the lower is for the return.

SPLIT SADDLE BOILERS

Split saddle boilers are available only for the Wildwood **6Kw, 9Kw, 12Kw, 12Kw Plus, 16Kw and 20Kw**, and are supplied as **two separate L-shaped boilers**. It is imperative that the plumbing of these boilers is done with the utmost care and full notice is taken of the above fact. These boilers are available in steel for 'Indirect' Cylinders only and each individual boiler has two **1" Male BSP stubs**.

To fit the boiler remove the fire board and the relevant blanking plugs from the back plate of the stove. The two stubs are passed through the stove body holes and the nuts and washers are sealed (with fire cement or high temperature mastic, where the stubs come through the body) and tightened on the rear of the stove body.

The **two halves must be horizontally joined** in the following manner (diagram 10)- **connect the two higher outlet stubs** for the single 28mm main gravity flow which should rise immediately from the boiler, **connect the two lower outlet stubs** and bring your 28mm return to this link.




PLUMBING DIAGRAMS


Diagrams 12 & 13 - Page 17 & 18 and Diagram 14 - Page 19

Typical 2 Pipe Central Heating Circuit in Conjunction with Split Saddle Boilers (Indirect Cylinder)

Diagram 12



Typical 4 Pipe Central Heating Circuit in Conjunction with Split Saddle Boilers (Indirect Cylinder)



ROOF BOILERS - ONLY available in conjunction with the split saddle boilers

Roof boilers are constructed with or without a top flue outlet and this must be specified, along with the stove model when ordering.

They have two 1" **Male BSP stubs**.


They are used only in conjunction with the split saddle boilers for your stove model, to increase the boiler output and reduce room output.

Plumbing this extra boiler with the split saddle boilers requires the **main gravity-flow** to be taken from the split saddle boilers' **top** tapings' link to the **lower tapping of the roof boiler** and then continued on from the **higher tapping of the roof boiler** upwards. Therefore the main gravity-flow runs from the link of the upper tapings of the split saddle boilers, through the roof boiler and upwards. All this pipework should be in 28mm pipe to the cylinder and gravity/heat leak radiator.

Fitting and Plumbing of Split Saddle Boilers with Roof Boiler

Diagram 14

Gravity Load 30% of total boiler output.
Plumb Gravity Flow in series through Roof Boiler if fitted.



AQUASTAT CALIBRATION

Only applicable for the WILDWOOD 20KW fitted with the 53000Btu split saddle boiler

This stove has an Aquastat fitted as standard (diagram 15), and in conjunction with High and Low pipe thermostats assists the stove to maintain the boiler temperature by automatically allowing either more or less air into the fire chamber via the airwash depending on the Control Knob setting.

FITTING INSTRUCTIONS IF NOT FACTORY FITTED

The **copper capillary wire and phial are delicate and will be easily damaged if handled roughly.** With the two M6 x 10 set screws and washers, fit the Aquastat control to its box at the rear of the 20Kw Stove, carefully fit the phial flat end first into its boiler tapping. When viewed from the rear this is located immediately below the right hand flow tapping and to the left of the Aquastat box, it is the tapping which is flattened at its top and has a horizontal hole through it for the split pin to hold the phial in place.


CALIBRATION INSTRUCTIONS

The **Aquastat control must be calibrated.** It is the round flapper plate on this device that must be set. With the stove alight, the boiler temperature at 55°C and the control knob in the middle (4-5) of its range, the flap plate should be just on the point of closing, adjust the position of the flap plate by means of the 5mm set screw and nuts either side of the flap plate until this is achieved and then tighten the nuts.

OPERATION

Close both primary and secondary air inlets and set thermostat dial to number 6. This will now allow the stove to work thermostatically according to the water temperature. Adjust the thermostat as required to suit demand.

Diagram 15



FAULT FINDING

A) Stove smokes on lighting or when fire door is opened

Flue ways blocked - sweep chimney and flue.

Baffle incorrectly fitted.

Adverse wind conditions, or down draught - check height and diameter of chimney.

Flue not connected (or not sealed) to appliance or chimney .

B) Fire fails to burn overnight - fuel burnt through

Insufficient dry fuel.

Air supply too great for fuel load.

Fire door seal damaged.

Door adjustment too slack.

Door glass sealing rope damaged or missing.

Insufficient bed of wood ash (when burning wood).

C) Fire fails to burn overnight - fuel not burnt

Insufficient air supply for fuel load.

Wood fuel beyond 18% moisture content and therefore too wet.

All section **A** applies also.

Fuel load not raised to a high enough temperature before closing to slumber.

Boiler pipe thermostats set too low or not fitted at all.

D) Stove cannot be closed to slumber and fuel burns too fast

Air controls open.

If the above are closed and/or shut then **air is getting into stove** from elsewhere.

Check if door and glass rope seals are damaged or not seating.

If rear flue outlet is being used, is the flat top / canopy seated on correctly.

Check all flue connections are airtight. Check if flue blanking plate is airtight.

Go through installation procedures and cautionary notes.

Chimney draw too fast - fit flue stabiliser.

E) Door glass sooting up

Allow stove to reach body temperature before closing air wash.

Primary air inlet open, whilst air wash control is shut.

Use bottom air as choke only - i.e. **minimal use**.

Fuel load too close to the door.

F) Boiler fails to reach operating temperature

Fuel load too wet.

Boiler load too great - check Btu output required for circuit.

Fit High and Low pipe thermostats.

Fuel load too small for demand.

Insufficient air supply for fuel load and demand.

G) If the stove gets too hot in the room whilst the boiler output is too low

Consider fitting a roof boiler - see your dealer for details or contact us.

FUME EMISSION

WARNING NOTE: WHEN PROPERLY INSTALLED AND OPERATED THIS APPLIANCE WILL NOT EMIT FUMES OR SMOKE TO THE ROOM. OCCASIONAL FUMES FROM DE-ASHING AND RE-FUELLING MAY OCCUR. PERSISTENT FUME OR SMOKE EMISSION TO THE ROOM MUST NOT BE TOLERATED. IF EMISSION DOES PERSIST THEN THE FOLLOWING IMMEDIATE ACTION MUST BE TAKEN.

A OPEN ALL DOORS AND WINDOWS TO VENTILATE THE ROOM

B LET THE FUEL OUT AND SAFELY DISPOSE OF FUEL FROM THE APPLIANCE

C CHECK FOR FLUE OR CHIMNEY BLOCKAGE AND CLEAN IF NECESSARY

D DO NOT ATTEMPT TO RELIGHT THE FIRE UNTIL THE CAUSE OF THE FUMES HAS BEEN IDENTIFIED, IF NECESSARY SEEK PROFESSIONAL ADVICE

WILDWOOD DOUBLE STOVES
ADDITIONAL
INSTALLATION AND OPERATING INSTRUCTIONS

HEARTH


The stove must stand on a fireproof hearth which must be at least **127mm thick and constructed of a non-combustible material**. The positioning of the stove and the size of the hearth is governed by Building Regulations for Class 1 Appliances. These regulations state that the hearth must extend at least **300mm** in front and **150mm** to the side of the stove. This can be covered with decorative tiles so long as these are also non-combustible. There must be **no combustible material** (i.e. wooden wall panels, skirting boards, beams etc) **within 700mm of the rear of the stove**. The area of hearth will need to be **correspondingly deeper, with the stove needing two front extensions of 300 mm**.

FIRE BOARD RETAINER BRACKETS

These are the two angled pieces of steel with two holes in each bracket which are fitted onto the baffle support pins either side of the stove before locating the baffle (diagram 16).

BAFFLE AND FLUE OUTLET

The baffle hangs between the fire board retainer brackets, on the baffle support pins, two on either side of the stove. The dip in the middle of the baffle should be under the fixed top flue outlet.



AIR CONTROLS

The main airwash controls are linked together to allow for equal and even air flow throughout the stove. The primary air controls are not linked, so these will need adjustment from ether side.

FUEL LOADING

When loading fuel be careful to have a fuel bed distributed evenly across the stove. Bear in mind this double stove will reach only a semi-cleanburn state if the fire is just at one end of the stove.

FLAT TOP / CANOPY

Please note that all flat tops and profiled flat tops are welded to the stove body, only low and high canopies can be removed from the stove to lighten it whilst moving it.

THE WOODWARM STOVES GUARANTEE

Metal Developments Ltd offer a five year guarantee which covers the main structure of the stove including the construction and quality of workmanship.

In the unlikely event of any failure we will replace any defective part free of charge, labour cost excluded.

This guarantee is invalid if the stove is not assembled, installed or operated as per these instructions or does not comply with current building regulations and any regional legislation in force at the time.

Metal Developments Ltd does not guarantee the onsite assembly, installation or operation of the stove. Please seek advice from your stove supplier / installer for any relevant guarantees applicable to the installation.

Metal Developments Ltd will not be held liable for any consequential or incidental loss, damage or injury, however caused.

Claims under this guarantee should be first made through your Woodwarm Stove retailer.

This guarantee is only applicable in the UK.

Nothing in this guarantee shall effect your statutory rights.

Exclusions

The following consumable parts are not covered by this guarantee : -

Logguard, Baffle Plate, Operating Tool, Fire Boards, Glass Panels and Door Seals.

Paint is also excluded from the guarantee as it will eventually deteriorate due to the normal working of the stove.

Your assistance is requested by filling in and returning the product Registration and Guarantee Form, this will help maintain our records and assist us in identifying your stove in the unlikely event of any problem occurring and also when you need to order any spare parts.

Useful Contacts

HETAS

PO Box 37
Bishops Cleeve
Gloucestershire
GL52 9TB
www.HETAS.co.uk

Solid Fuel Association

The Old School House
Church Street
Sutton In Ashfield
Nottinghamshire
NG17 1AE
Tel: 0800 600000

The National Association Of Chimney Engineers

(N.A.C.E. Ltd)
PO Box 849
Metheringham
Lincoln
Lincolnshire
LN4 3WU
Tel: 01526 322555
Fax: 01526 323181
E-mail: info@nace.org.uk

The National Association of Chimney Sweeps

Unit 15
Emerald Way
Stone Business Park
Stone
Staffordshire
ST15 0SR
Tel: 01785 811732
www.chimneyworks.co.uk

Database of wood fuel suppliers.

National Energy Foundation (NEF)

Tel: 0800 138 0889
www.logpile.co.uk
Searches can be made on post code, county and by supplier.

Guild of Master Sweeps

Tel: 01953 451322
www.guild-of-master-sweeps.co.uk

**DETAILS OF PRODUCT REGISTRATION
FOR OWNER RETENTION**

MODEL NUMBER AND SERIAL NUMBER OF STOVE M ---

(Found on the data plate located on the pull-out plate on right hand underside of stove also on the front of this booklet)

Date of Purchase / 20.....

Date of Installation / 20.....

SUPPLIERS DETAILS

Suppliers Invoice Number.....

Name.....

Address.....

.....

.....

Phone Number.....

INSTALLERS DETAILS

Name.....

Address.....

.....

.....

Phone Number.....**HETAS Registration Number**.....

SPARE PARTS

Use only Metal Developments Ltd approved replacement parts.

14mm Main Fire Door Rope
Door Glass Ladder Rope
Door Glass (2no per stove)
Fire Boards
Operating Tool
Door Hinge Pin
Baffle
Log Guard

State model
State model
State model and number required
State model and see chart (30mm)

Stainless Steel or Brass
State model and if Boiler(s) fitted
State model